i-FlashDrive EVO　フォーマット方法
※必ずデータをパソコンに退避してから行って下さい※

|	
①	http://www.photofast.com/　をパソコンで検索しますと下記HPに飛びますのでDOWNLOADをクリックします
②	お客様のパソコンによってWindowsまたはOS XどちらかのDOWNLOADをクリックします
③	ダウンロードしたファイルを解凍し、ファイルを開け、「i-FlashDrive Format Tool.exe」をダブルクリックします（画像はWindowsです）

④	下記の画面が出てきますので、フラッシュメモリをパソコンに挿します
	i-FlashDrive Format Tool v1.09 Drive info　N/A Volume Label　IFLASHDRIVE No device connected! Run　　Cancel **Powered by PhotoFast®**
⑤	フラッシュメモリを挿すと、下記の表示に変わりますのでRUNをクリックします
	i-FlashDrive Format Tool v1.09 Drive info　G:/14.76 GB Volume Label　IFLASHDRIVE All data on drive will be deleted. Please backup in advance. Run　　Cancel **Powered by PhotoFast®**
⑥	下記の画面が表示されますのでAgreeをクリックします
	i-FlashDrive Format Tool End-User License Agreement This End-User License Agreement (EULA) is a legal agreement between you (either an individual or a single entity) and the mentioned author (PhotoFast Co. Ltd.) of this Software for the software product identified above, which includes computer software and may include associated media, printed materials, and "online" or electronic documentation ("SOFTWARE PRODUCT"). By installing, copying, or otherwise using the SOFTWARE PRODUCT, you agree to be bounded by the terms of this EULA. If you do not agree to the terms of this EULA, do not install or use the SOFTWARE PRODUCT. SOFTWARE PRODUCT LICENSE Agree　　Disagree
⑦	下記の画面が表示されますのでRUNをクリックします
	i-FlashDrive Format Tool All data on i-FlashDrive will be deleted. Please backup data before proceeding. Run　　Cancel
⑧	こちらの画面で完了となります
	i-FlashDrive Format Tool v1.09 Drive info　G:/14.76 GB Volume Label　IFLASHDRIVE Device format succeeded, please unplug and re-insert your device! Run　　Cancel **Powered by PhotoFast®**